

Lead free solder wire Flexsol 903



Technical data Flexsol 903 Ver: 2.1 19-05-11 latest version on www.interflux.com

Page 1

Lead free, No-clean and halide free solder wire

Description:

Interflux[®] **Flexsol 903** Lead-Free, No-Clean solder wire contains no halides and is recommended for **all class** (IPC-A-610) soldering.

It is designed to minimize flux spattering during soldering also at higher temperatures.

Flexsol 903 is designed to be used in both manual and automatic wire soldering applications.



More information:

Work instructions	2
Handling	2
Test results	3
Packaging	4

Key advantages:

- Very low spattering
- Classification to IPC and EN: RO LO
- Absolutely Halogen Free
- Long tip-life
- 3 flux channels
- Very good wetting on Cu, Ag, Sn ...
- Suited for automatic soldering

Availability

Flux type: IF 903 *Flux content:* 2,2% w/w — 3,5% w/w

		diameters	
alloy	melting point	0,35 0,50 0,70 1,00 1,50 2,00	
Sn96,5Ag3Cu0,5	217°C—219°C	• • • • • •	
Sn99Ag0,3Cu0,7	217°C-227°C	• • • • • •	
Sn99,3Cu0,7	227°C	• • • • • •	
 available 			



Work instructions

Manual soldering

The working temperature is between 320°C and 390°C. For more dense metals like Nickel, the temperature may be elevated to 420°C.

Choose the correct soldering tip: to reduce the thermal resistance, it is important to create a large contact surface with the component and solder pad.

The use of a good soldering station is important in order to always have the correct temperature on the soldering joint. Use a soldering station with a response time as short as possible.

Heat up the surfaces of both component and island simultaneously. Slightly touch with the solder wire,

the point where component lead, soldering island and soldering tip meet (the small quantity of solder ensures a drastic lowering of the thermal resistance). Add subsequently without interruption, the correct amount of solder close to the soldering tip without touching the tip. It is important that no solder wire is making contact with

the soldering tip during soldering to avoid flux spitting and premature flux consumption!

Handling

Storage

Store the solder wire in a clean environment between 0°C and 40°C

<u>Handling</u>

To avoid spool and wire damage, handle package with care





Technical data Flexsol 903



ISO 9001

AV.

Test results conform EN 61190-1-2(2002) and IPC J-STD-004A

Property	Result	Method
Chemical		
flux designator	RO LO	J-STD-004A
	w	EN61190-1-3 (2002)
	F-SW 31	DIN 8511
	1.1.1	ISO 9454
qualitative copper mirror	pass	J-STD-004A IPC-TM-650 2.3.32
	pass	TR-TSY-000078 13.1.6
qualitative halide		
silver chromate (Cl, Br)	pass	J-STD-004A IPC-TM-650 2.3.33D
	pass	TR-TSY-000078 13.1.4
spot test (F)	pass	J-STD-004A IPC-TM-650 2.3.35.1A
	pass	TR-TSY-000078 13.1.5
quantitative halide	0,00%	J-STD-004A IPC-TM-650 2.3.35C
Environmental SIR test	pass	J-STD-004A IPC-TM-650 2.6.3.3B
qualitative corrosion, flux	pass	J-STD-004A IPC-TM-650 2.6.15C

